


Despiece - Diagram



Ref.	Nº	Repuesto	Spare Part
sh7000-001	1	Base	Base
sh7000-002	2	Tornillo M5*10	Screw M5*10
sh7000-003	3	Soporte caja de conexión	Junction box support
sh7000-004	4	Caja de conexión	Junction box
sh7000-005	5	Tornillo M8*35	Screw M8*35
sh7000-006	6	Arandela M8	Washer M8
sh7000-007	7	Arandela grower M8	Grower washer M8
sh7000-008	8	Motor	Motor
sh7000-008x		Motor X	MotorX
sh7000-008a		Masas Motor	Mass Motor
sh7000-008x1		Chaveta de la masa	Mass peg
sh7000-008x2		Cojinete del motor	Motor Bearing
sh7000-009	09	Condensador	Capacitor
sh7000-010	10	Soporte condensador	Capacitor support
sh7000-011	11	Tornillo M5*10	Screw M5*10
sh7000-012	12	Arandela M8	Washer M8
sh7000-013	13	Tuerca M8	Nut M8
sh7000-014	14	Amortiguador	Bumper
sh7000-015	15	Goma amortiguador	Rubber bumper
sh7000-016	16	Depósito	Deposit
sh7000-016x1a		Area perforada salida Xa	Drilled exit area Xa
sh7000-016x1b		Area perforada salida Xa	Area perforada salida Xb
sh7000-016x2		Rampa de salida X2	Exit ramp X2
sh7000-016x3		Rampa de entrada X3	Entry ramp X3
sh7000-017	17	Tornillo M	Screw M
sh7000-018	18	Tapa depósito	Deposit lid
sh7000-018x		Tapa depósito X	Deposit lid X
sh7000-019	19	Tornillo negro	Black screw
sh7000-020	20	Lámpara	Lamp
sh7000-021	21	Portalámparas	Lamp holder
sh7000-022	22	Cortinas	Curtains
sh7000-022x		Cortinas X	Curtains X
sh7000-023	23	Soporte cortinas	Curtains support
sh7000-024	24	Remache	Rivet
sh7000-025	25	Tornillo M5*10	Screw M5*10
sh7000-026	26	Visagra	Hinge
sh7000-027	27	Arandela M5	Washer M5
sh7000-028	28	Amortiguador inox	Stainless steel bumper
sh7000-029	29	Tapa	Top
sh7000-030	30	Tapón goma	Rubber top
sh7000-031	31	Remache	Rivet
sh7000-032	32	Ventilador	Fan
sh7000-032x		Ventalidor X	Fan X
sh7000-033	33	Resistencia	Heating element
sh7000-033x		Resistencia X	Heating element X
sh7000-033x1		Termostato Klixon X	Klixon X thermostat
sh7000-034	34	Interruptor	Switch

FRUCOSOL SH-7000

Ref.	Nº	Repuesto	Spare Part
sh7000-034x		Interruptor X	Switch X
sh7000-035	35	Fusible	Fuse
sh7000-036	36	Portafusible	Fuse holder
sh7000-037	37	Tapa delantera	Front cover
sh7000-038	38	Tuerca enjaulada	Caged nut
sh7000-039	39	Tornillo sujección	Fixing screw
sh7000-040	40	Brazos	Arms
sh7000-041	41	Bandeja	Tray
sh7000-042	42	Carro	Cart
sh7000-043	43	Rueda con freno	Wheel with brake
sh7000-044	44	Rueda	Wheel
sh7000-045	45	Cable de red	Network cable
sh7000-046	46	Cubierta cable de red	Network cable cover
sh7000-047	47	Tornillo M3*10	Screw M3*10
sh7000-048	48	Interruptor de seguridad	Security micro
sh7000-049	49	Soporte micro de seguridad	Security micro support