


Despiece - Diagram



Ref.	Nº	Repuesto	Spare Part	Price
gf1000-001	1	Goma Tórica	Rubber ring	
gf1000-002	2	Tuerca	Nut	
gf1000-003	3	Pieza de apriete	Tightening part	
gf1000-004	4	Filtro	Filter	
gf1000-005	5	Vástago	Rod	
gf1000-006	6	Latiguillo	Hose	
gf1000-007	7	Tornillo M12*100	Screw	
gf1000-008	8	Mordaza	Fixing part	
gf1000-008 B		Mordaza B	Finxing part B	
gf1000-009	9	Tornillo M8*30	Screw M8*30	
gf1000-010	10	Carcasa	Cover	
gf1000-011	11	Luces Led	Led lights	
gf1000-012	12	Difusor	Diffuser	
gf1000-013	13	Campana	Hood	
gf1000-014	14	Tornillo M4*10	Valve	
gf1000-015	15	Cuello de la campana	Neck hood	
gf1000-016	16	Tapa	Lid	
gf1000-017	17	Válvula	Valve	
gf1000-018	18	Chasis interno	Internal frame	
gf1000-019	19	Micro de seguridad	Security micro	
gf1000-020	20	Tornillo M6*80	Screw M6*80	
gf1000-021	21	Portapilas	Battery holder	
gf1000-022	22	Tuerca M6	Nut M6	
gf1000-023	23	Pilas	Batery	
gf1000-024	24	Conector Válvula	Valve connector	